HP Pavilion ZD7000 Wi-Fi Card Replacement

Bad wireless reception? Replace the Wi-Fi card in your HP Pavilion ZD7000.

Written By: Shantel



INTRODUCTION

How to remove the Wi-Fi Card

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Battery



- Begin by turning the laptop over so that you can see the bottom of the computer.

Step 2



- Slide the battery release switch to the right while simultaneously lifting up the battery.


Step 3 — Wi-Fi Card





- Unscrew the 2 screws from the plate that cover the Wi-Fi card.
- Remove the cover.

Step 4





- Disconnect these 2 antenna wires (which eventually connect to the monitor) from the Wi-Fi card.
  - For reassembly, note where the black and white cables connect to the card.
- Release the Wi-Fi card from the laptop by pressing the metal hinges on either end of it.
- Gently remove the card from laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 10:43:30 PM.